



HOW TO PERFECT YOUR INSTALLATION



SCAN FOR
INSTALLATION VIDEO



www.solaskirt.co.uk



info@solaskirt.co.uk

1 Trim the rails to 30mm

Trimming the rail to 30mm **prevents** SolaSkirt from **warping**. This is best undertaken with a **multitool**.



2 Fit the first Corner Kit

Start by installing a Corner Kit to create a **solid base** for attaching the lengths. This ensures a **more efficient** installation by optimising the use of each piece's full length.



3 Pre-fit and evenly distribute the clamps

Installing the clamps first and spacing them correctly with the Double Clamps **around 55cm** from the Single Clamps. This allows for more **precise** and **faster** installations.



4 Overlap in the Double Clamps for extra rigidity

For SolaSkirt to withstand all weather, including high winds, **overlap** the lengths in the Double Clamps and **tighten securely** with the grub screws. This ensures **firm anchoring** and **long-lasting protection**.

DON'T FORGET!



5 Push the skirt down for a tighter fit

Pigeons are tenacious and can exploit even small gaps. SolaSkirt's angle of protrusion can be adjusted to a **narrower angle** to block these gaps effectively and **fit in tight spaces**. Ensure **no gap exceeds 30mm**.





HOW TO PERFECT YOUR INSTALLATION



SCAN FOR
INSTALLATION VIDEO



www.solaskirt.co.uk



info@solaskirt.co.uk

6 Mitre the Corners for a perfect finish

The corner angle provided is suitable for most installations. However, if the system is mounted at an unusual height, the alignment may be impacted as the lengths are adjusted to match the roof profile. To resolve this, **mark where the overlap occurs and trim any excess** (see No. 9 below for further details).



7 Overlap SolaSkirt upwards

Overlapping SolaSkirt upwards creates a more **seamless fit** from below, giving off the impression of a **single continuous length**.



8 Use a Chimney Kit for improved airflow

Fitting our Chimney Kits at the **top of each array** allows hot air to escape, drawing in cooler air in at the bottom of the array which **increases ventilation**.



9 Cut either side of the skirt and bend to break off a piece or to mitre a corner

Use tin snips to cut along both sides of the skirt, then bend the material to separate a smaller piece that can effectively plug any gaps. This process is **straightforward** and results in a **clean separation**.



10 Trim around obstacles & irregular roofs, if needed

Level up your installations by cutting around obstacles and **adapting** to irregular roof profiles. This ensures SolaSkirt **fits perfectly** and delivers a brilliantly **precise finish** which **customers love**.

